

MIX MAX

BE BETTER

INSTRUCTION - SPIDER TENT



1

After unpacking the tent, place it on a flat surface.



2

Open the zipper on the legs of the tent and put the weight inside. Next, close the zipper on each leg.



3

Put the plug into the socket to start the process of inflating the tent.



4

Remember not to cover the ventilator with fabric when inflating. Wait for a while until the tent is filled with air.



5

Unpack 4 walls of the tent and fasten them with zippers.



6

When the tent is unfolded, start attaching it to the ground with pins.



7

First, attach each leg of the tent to the ground with four pins.



8

Then fix the tent walls with pins through the eyelet in the middle of each wall.



9

Use guy lines to stabilize the tent. After mounting the pins and lines, the tent is ready to use.

MIX MAX

BE BETTER

DISASSEMBLY STEP-BY-STEP

- 1 Unzip all the walls.
- 2 Turn off the power.
- 3 Open the zipper on the leg with the ventilator.
- 4 Air will start escaping from the tent.
- 5 Start rolling the legs, from the end of the leg to the center of the tent.
- 6 First, fold the opposite leg to the one with the ventilator.
- 7 Then fold two more legs without a ventilator (excess air will escape through the unfastened zipper).
- 8 At the end, roll up the whole tent from the inside towards the leg with the ventilator, so that no air remains in the pipes of the tent.
- 9 Pack the rolled-up tent in the transport bag, so that the ventilator is on top of the bag, which makes it less exposed to mechanical damage during transport.